

Type UNI-WM-HD
 Heavy Duty pneumatisk aktuator
 Dobbeltvirkende (DA)

Momenttabel (Nm)

Type	Stilling	Supply tryk (bar)						
		3	3,5	4	5	5,5	6	7
		Moment (Nm)						
HD60DA	start/slut	301	351	401	501	551	602	702
	midt	182	212	242	303	333	363	424
HD120DA	Start/slut	600	700	800	1000	1100	1200	1400
	midt	368	429	490	613	674	735	858
HD140DA	start/slut	700	816	933	1166	1283	1400	1633
	midt	424	494	565	706	777	848	989
HD190DA	Start/slut	950	1109	1267	1584	1742	1901	2217
	midt	583	680	777	971	1068	1166	1360
HD280DA	start/slut	1407	1642	1876	2345	2580	2814	3283
	midt	840	980	1120	1400	1540	1680	1960
HD300DA	Start/slut	1551	1810	2068	2585	2844	3102	3619
	midt	900	1050	1200	1500	1650	1800	2100
HD380DA	start/slut	1943	2266	2590	3238	3561	3885	4533
	midt	1140	1330	1520	1900	2090	2280	2660
HD600DA	Start/slut	3061	3571	4081	5101	5611	6122	7142
	midt	1851	2160	2468	3085	3394	3702	4319
HD900DA	start/slut	4511	5263	6015	7519	8271	9023	10526
	midt	2729	3183	3638	4548	5002	5457	6367
HD1200DA	Start/slut	6109	7127	8145	10181	11199	12218	14254
	midt	3695	4310	4926	6158	6773	7389	8621
HD1500DA	start/slut	8167	9528	10889	13611	14972	16334	19056
	midt	4940	5763	6586	8233	9056	9879	11526
HD2000DA	Start/slut	9944	11602	13259	16574	18231	19889	23203
	midt	6014	7017	8019	10024	11026	12029	14033
HD2500DA	start/slut	12511	14596	16681	20851	22936	25022	29192
	midt	7567	8828	10089	12611	13872	15134	17656
HD3000DA	Start/slut	15038	17545	20051	25064	27570	30077	35089
	midt	9095	10611	12127	15159	16675	18191	21222
HD4000DA	start/slut	20404	23804	27205	34006	37407	40808	47609
	midt	12340	14396	16453	20566	22623	24680	28793
HD5000DA	Start/slut	25451	29693	33935	42419	46661	50903	59386
	midt	15393	17959	20524	25655	28221	30786	35917

Type UNI-WM-HD
 Heavy Duty pneumatisk aktuator
 Dobbeltvirkende (DA)

Momenttabel (Nm) fortsat

Type	Stilling	Supply tryk (bar)						
		3	3,5	4	5	5,5	6	7
		Moment (Nm)						
HD6000DA	start/slut	30407	35475	40543	50679	55747	60815	70950
	midt	18391	21456	24521	30651	33716	36782	42912
HD8000DA	Start/slut	40852	47660	54469	68086	74895	81704	95321
	midt	24675	28788	32900	41125	45238	49350	57575
HD10000DA	start/slut	50903	59387	67871	84839	93323	101807	118774
	midt	30787	35918	41049	51311	56442	61574	71836
HD12000DA	Start/slut	60814	70949	81085	101356	111492	121628	141899
	midt	36781	42911	49041	61301	67431	73562	85822
HD15000DA	start/slut	75000	87500	100000	125000	137500	150000	175000
	midt	45000	52500	60000	75000	82500	90000	105000
HD20000DA	Start/slut	100000	116666	133333	166666	183333	200000	233333
	midt	60000	70000	80000	100000	110000	120000	140000
HD25000DA	start/slut	125000	145834	166667	208334	229167	250001	291667
	midt	75000	87500	100000	125000	137500	150000	175000
HD30000DA	Start/slut	150000	175000	200000	250000	275000	300000	350000
	midt	90000	105000	120000	150000	165000	180000	210000